

CT-5801 Terminal module (Required)

1 Module Description

The terminal module is used to stabilize internal bus communication and it is required.


The terminal module CT-5801 has no process data and no configuration parameters.

CT-5801 requires no configuration and occupies no slot in configuration.

2 Technical Parameters

N/A

3 Hardware Interface



- ① Module Type
- ③ Internal Bus
- ④ Buckle
- ⑤ Grounding Spring Sheet
- ⑥ Terminal Cover

3.1 LED indicator definition

N/A

A Dimension drawing

